

CALL FORWARD

To program:

Do not lift handset

Press **CALL FWD** key

Dial 5-digits you are forwarding to

Press **CALL FWD** key

To cancel:

Do not lift handset

Press **CALL FWD** key

RING AGAIN

If you hear a busy tone when dialing another extension and want the system to call you back when their line is free:

From busy tone:

Press **RING AGAIN**

Hear Confirmation tone

Hang up

To answer a call ringing back to your station:

Lift handset

Press **RING AGAIN**

To cancel a call back request:

Press **RING AGAIN**

Note: If you do not respond to Ring Again recall within 4 rings feature automatically cancels.

AUTO DIAL

To program:

Do not lift handset

Press **AUTO DIAL** key

Dial number (on or off campus)

Press **AUTO DIAL** key

To call:

Lift handset to talk

Press **AUTO DIAL** key

SYSTEM TONES

Special dial tone:

Three beeps followed by a steady dial tone is your indication that you may proceed with feature activation.

Confirmation tone:

Two short bursts of tone followed by silence.

This is heard after a feature access code has been entered and indicates the feature has been successfully activated.

Reorder tone:

A rapid busy signal that indicates you have attempted to activate a restricted feature or have entered an access code incorrectly.

DISTINCTIVE RINGING

Calls from within the system:

You will hear a long ring

Calls from outside the system:


You will hear a long ring followed by one short ring.

Ring Again (Call Back) Recall: You will hear a long ring followed by two short rings

CIS/COMMUNICATIONS

Box 1885

3-2007



TELEPHONE USER GUIDE

MULTI LINE SET

FOR REPAIR, DIAL 0

PLACING CALLS

Within the system:

Lift handset

Dial 5-digit extension number

Outside the system:

Dial 8+ telephone number

HOLD

To place a call on hold:

Ask party to hold

Press **Hold**

TRANSFER

To transfer a call to another extension:

Press **TRANSFER** key

Hear special dial tone

Dial 5-digit extension number

Announce call

Press **TRANSFER** key

Hang up

If extension is busy or does not answer:

Press flashing line key

You are reconnected to the first party

CALL WAITING

To answer your call waiting signal

Ask first party to hold

Press **CALL WAIT** key

Original call is automatically held

To Re-enter the Original call:

Press key next to blinking light

You may flip-flop between calls by alternating keys

3-WAY CONFERENCE

To add a third party to an existing call:

Ask first party to hold

Press **TRANSFER** key

Hear special dial tone

Dial third party's number

When party answers

Press **TRANSFER** key

All three parties are connected

To drop the last call and continue speaking with first party:

Press **TRANSFER** key

If station is busy or does not answer:

Press **TRANSFER** key

CALL PICKUP

To answer an incoming call ringing at another extension number within your call pick up group:

Lift handset

Hear dial tone

Press **CALL PICKUP** key

You are connected to incoming call

LAST NUMBER REDIAL

Lift handset

Press **##**

CALL PARK

To park a call against your extension number so that it can be retrieved from another telephone:

To park:

Ask party to hold

Press **CALL PARK** key

Hear special dial tone

Hang up

To retrieve from any telephone:

Lift handset

Hear dial tone

Press **#78**

Dial 5-digit extension number call parked against

CONFERENCE

A maximum of ten parties may be conferenced without assistance from the operator.

Call first party

Press **CONFERENCE** key

Dial desired number

Press **CONFERENCE** again

Continue process until all parties are on the line.

BUSY LAMP FIELD

Provides monitoring (busy indication) of other phone numbers

Key may also be used as an auto dial to specified number

Please call Communications at 3-2007 to add features.