


Knowledgebase > Phones & Conferencing > Telephones > How to Manually Reset Your Cisco Phone

How to Manually Reset Your Cisco Phone


Don Rogers - 2025-07-15 - Comments (0) - Telephones

Steps to Manually Reset Your Cisco Desk or Wall Phone

1. Press the the button with the $\boldsymbol{gear\ icon}$ on it.



2. Press 5, or scroll down and select Admin Settings.




3. **Press 5**, or scroll down and select **Reset Settings**.



4. **Press 4**, or scroll down and select **Security**.



5. Press the **physical button** directly under the word "**Reset**".



If the above instructions do not fix the issue please try unplugging your phone and plugging it back in.